



How To Use

When you click the Weavy icon (weavy.exe), the application starts. This system has two design modes. One is a standard design mode. The other is a free painting design mode. You first choose which mode you want to design. The system then starts the design mode. You CAN NOT change the design mode after you select the mode at the first panel. If you want to try the other mode, please close the application and restart the application by clicking the desktop icon.

Standard design mode
 • with repetition



Free painting design mode
 • without repetition



* Menu



Paint Tool



Undo




Fill Tool




Clear



Change Panel
 (to How to Make Panel)



Change Panel
 (to Design Panel)




Rotate

(Free painting mode only)



* Finish Button

When you push "FINISH" button, the system saves your design.




Standard design mode

* Direction of warp yarns





* Direction and number of rotations of the cards

The final textile design is defined by the direction and number of rotations of the cards. 'Forward:4, Backward:4' means that the user first rotates all the cards four times in the forward direction and four times in the backward direction for this one set. The user repeats the set until he/she is satisfied with the length of the fabric.




Free painting mode

* Color change




You paint an arbitrary pattern on the band with the two colors by clicking. The system automatically derives rotation direction of each card at each step from the pattern.



You can use two colors (Foreground color and Background color) for each card.

* Rotate of Design Pattern



Rotate

When you want to rotate the design pattern, please push the "ROTATE" button.

